

Standard Concrete Skip



Product information

With a range of sizes available, Concrete Column Skips are used for pouring concrete, especially in formwork or columns where access could prove to be difficult.

**Volume
liter**

500

1,000